


TagScan: Simultaneous Target Imaging and Material Identification with Commodity RFID Devices

Ju Wang, Jie Xiong, Xiaojiang Chen,

Hongbo Jiang, Rajesh Krishna Balan, Dingyi Fang



Many applications are enabled by **passive** sensing



Gesture recognition



Virtual Reality




Elderly Monitoring




Intruder Detection

Current Solutions


Localization

[RTI'10], [VRTI'12], Google
[Nuzzer'13], [WiTrack'14],
[mTrack'15], [LiFS'16],... 


**RF-based
passive sensing**



Current Solutions





Current Solutions




Current Solutions

Localization

[RTI'10], [VRTI'12], 
[Nuzzer'13], [WiTrack'14],
[mTrack'15], [LiFS'16],... 

Motion tracking

[Wi-Vi '13], [WiFall'14], 
[AllSee'14], [WiKey'15],
[CARM'15], [EQ-Radio'16].

Gesture recognition

[WiSee'13],  Microsoft
[E-eyes'14], [WiDeo'15],
[WiDraw'15], [D-Watch'16]...


RF-based
passive sensing

Smart home,
Others...

Missing: target imaging and material identification

**Target
Imaging**

**Material
Identification**



Applications of Target Imaging and Material Identification



Robot Control

Robot adjusts its grip strength when picking egg and stone by using **material identification**



Security checking

Detecting concealed weapons by knowing **target shape and material type**

TagScan


A system identifies a target's material and images its shape simultaneously

- ***Low cost:***
 - cheap commodity RFID device.
- ***High accuracy:***
 - differentiating even Coke and Pepsi.
 - Imaging the body shape accurately.
- ***Easy deployment:***
 - Utilizing the phase and RSS readings.

How can we identify a target's material?




How can we image a target's shape?



Preliminary studies



Setup:

Place RFID tag on top of the cup and pour the **same amount** of liquid.





Key Observations:

- Different liquids have different Phase/RSS changes.
- Even Coke and Pepsi have an around 0.2 radians phase change difference.



Challenge :


Without knowing the target size, identifying material type is challenging



Material Feature Extraction

Background and limitation of past approaches

Considering a target that blocks the direct path:



RF propagation property

- > Phase constant β : Phase changes β over a wavelength.
- > Attenuation constant α : amplitude changes $e^{-\alpha}$ over a unit distance.

With Phase change $\Delta\phi$ and RSS change ΔR , we have:

$$\begin{aligned} -\Delta\phi &= 2(\beta_{air} - \beta_{tar})D \\ \ln 10^{\Delta R/20} &= 2(\alpha_{air} - \alpha_{tar})D \end{aligned}$$

Measurements

Constant


Unique for each material type

Past approaches use α_{tar} and β_{tar} for material identification

Material Feature Extraction

Background and limitation of past approaches

Considering a target that blocks the direct path:



RF propagation property

- > Phase constant β : Phase changes β over a wavelength.
- > Attenuation constant α : amplitude changes $e^{-\alpha}$ over a unit distance.

With Phase change $\Delta\phi$ and RSS change ΔR , we have:

2 Equations $\left\{ \begin{array}{l} -\Delta\phi = 2(\beta_{air} - \beta_{tar})D \\ \ln 10^{\Delta R/20} = 2(\alpha_{air} - \alpha_{tar})D \end{array} \right.$ \leftarrow 3 Unknowns

2 equations can not solve 3 unknowns!

Material Feature Extraction

Our solution:

By removing the unknown D , we define a feature:

$$\Omega = \frac{\ln 10^{\Delta R/20}}{\Delta \phi} = \frac{\alpha_{air} - \alpha_{tar}}{\beta_{tar} - \beta_{air}}$$

Advantage:

- Ω is unique for each material and independent of D .

Material Feature Extraction

Our solution:

By removing the unknown D , we define a feature:


$$\Omega = \frac{\ln 10^{\Delta R/20}}{\Delta \phi} = \frac{\alpha_{air} - \alpha_{tar}}{\beta_{tar} - \beta_{air}}$$

Advantage:

- Ω is unique for each material and independent of D .
- Ω can be calculated from RSS and phase readings.

Without knowing the target size, we employ the new feature Ω for material identification

Differentiating materials with feature Ω




The Ω values of 6 liquids are different from each other.

How can we identify a target's material?




How can we image a target's shape?



Preliminary studies


Setup:

Pour a liquid into the cup and increase the liquid height.




Key Observation:


- Linear relationship between phase changes and liquid heights (i.e. target widths).




Basic Imaging Idea




Basic Imaging Idea



Basic Imaging Idea




Basic Imaging Idea




Challenge :
Stitching target widths for imaging
is non-trivial

Starting points of target widths are unknown;




Starting points of target widths are unknown;
As a result, we may obtain wrong images:

How can we solve this problem?



Solution: Imaging with Two Arrays



Key Observation:

- Images estimated from different arrays **align** well if the starting points are estimated correctly.

Solution: Imaging with Two Arrays





Image from Array 1




Image from Array 2

Solution: Imaging with Two Arrays





Image from Array 1





Image from Array 2



Initial image estimate

Solution: Imaging with Two Arrays





Image from Array 1






Image from Array 2



Initial image estimate



Another image estimate

Solution: Imaging with Two Arrays





Image from Array 1







Image from Array 2



Initial image estimate



Another image estimate



Final image estimate

Multipath Problem:

Multipath signals break the linear relationship between phase change and target width

Solution: *Multipath Suppression*

Stage 1: Identifying the “clean” channels and tags




Fig. 1 Phase changes over different channels.





Fig. 2 Phase changes in hall environment.


However, this works well only in the environment with little multipath

Solution: *Multipath Suppression*

Stage 2: Enhancing the direct-path signal




(a) Phase shift of $\frac{4\pi f}{c} d \cos(\theta)$ at two adjacent tags.




Solution: *Multipath Suppression*


Stage 2: Enhancing the direct-path signal



(a) Phase shift of $\frac{4\pi f}{C} d \cos(\theta)$ at two adjacent tags.




(b) Phase shift of $4\pi \tau \Delta f$ at two adjacent channels.




Solution: *Multipath Suppression*


Stage 2: Enhancing the direct-path signal



(a) Phase shift of $\frac{4\pi f}{C} d \cos(\theta)$ at two adjacent tags.



(b) Phase shift of $4\pi \tau \Delta f$ at two adjacent channels.



Implementation & Evaluation

Implementation

- **Reader and Tag:** **one** Impinj Speedway R420 readers; **16** cheap Alien ALN-9634 tags.
- **Environments:** Hall, lab-office and library, w.r.t, *low, medium* and *high* multipath.



Reader



Antenna



Tag

Material Identification Performance



Material Identification for 10 Liquids

	A	B	C	D	E	F	I	L	M	N
A	1									
B		0.94						0.06		
C			0.99				0.01			
D				1						
E					0.95				0.05	
F						0.99			0.01	
I							1			
L								1		
M						0.05			0.95	
N										1

A : Vinegar B : CoKe C : Soy Source D : Liquor E : Beer
F : Purified water I : Saline Water L : Sweet Water
M: Whole milk N: Skimmed milk

Material identification accuracy is higher than 94%.

Similar Liquid Material identification



Coke



Pepsi

	Coke	Pepsi
Coke	0.93	0.07
Pepsi	0.06	0.94

Higher than 90% accuracy for identifying Coke and Pepsi.



Skimmed
milk



Whole
milk


	Skimmed	Whole
Skimmed	1	
Whole		1

100% accuracy for identifying Skimmed and Whole milk.

Target Imaging Performance




Imaging for Target with Different Shapes and Materials




Triangle shape (plastic & water)



Hexagonal shape (plastic & water)




Rectangular shape cement pillar



Circular shape (plastic & water)


Imaging for Target with Different Shapes and Materials



Two more arrays added!




Hexagonal shape (plastic & water)




Circular shape (plastic & water)

See-through the wall imaging



Human target through wall imaging

See-through the wall imaging



Two-target through wall imaging

Conclusion

- TagScan performs **material identification** and **target imaging** *simultaneously*.
- *A new approach to **identify materials**, independent of target size.*
- A novel method for imaging targets, using RSS and phase.